



INFORMATION SHEET

FERIENDORF SEEBLICK
WELLNESS

USAGE SAUNA & HOT TUB



Welcome to the Premium Tiny-Chalet

Guidelines for using the Sauna & Hot Tub

We are delighted to offer you exclusive wellness options in your Premium Tiny Chalet. Please read the following instructions carefully to enjoy the hot tub and sauna safely.



10 important guidelines for using the Sauna and operating the Sauna heater

- 1. Self-responsibility:** Using the sauna is at your own risk. Only use the sauna if your health condition allows it.
- 2. Setting the temperature:** The left dial of the Harvia sauna heater controls the temperature. A comfortable range is between 80°C and 90°C. Turn the dial clockwise to increase the temperature.
- 3. Using the timer:** The right dial serves as a timer. Set the operating time to up to 4 hours for immediate heating, or use the delayed start function (1–8 hours) for later use. Important: Even when using the delayed start, the sauna must not be left unattended.
- 4. Allow heating time:** The sauna takes about 20 minutes to heat up. Stay nearby when using the immediate heating function.
- 5. Pouring water on the stones:** For a steam infusion, use only the provided ladle and pour water slowly and in small amounts directly onto the hot stones. A moderate amount of water is sufficient to increase humidity to a comfortable level.
- 6. Caution – Burn hazard from the hot heater:** The sauna heater becomes very hot. Avoid contact with the heater to prevent burns.
- 7. Use a towel as a base:** Always cover the seating and lying areas with a sufficiently large sauna towel to protect the wood.
- 8. No items on or near the sauna heater:** Do not use the sauna to dry items, clothing, or laundry. Do not place any objects on the heater to avoid fire or damage.
- 9. Supervision required:** Children are only allowed in the sauna under the supervision of an adult.
- 10. Turn off and ventilate after use:** Turn both dials to "0" to completely switch off the sauna. Leave the door slightly open to allow moisture to escape and the sauna to dry.



10 important guidelines for using the Hot Tub

- 1. Prepare the Hot Tub:** Use only the provided wood. You will find wood in the round wood stack next to the hot tub. Additionally, you can take wood from the wood pile located next to the electric car charging station on the resort grounds (on the left).
- 2. Lighting the Fire Safely:** Place a moderate amount of wood in the hot tub stove. Light the wood using fire starters and avoid using accelerants such as gasoline or alcohol.
- 3. Allow Heating Time:** The hot tub will need about 1 hour to reach the desired temperature, depending on the outside temperature.
- 4. Check the Temperature Regularly:** Monitor the water temperature with the thermometer to ensure it does not exceed 40°C.
- 5. Distribute the Heat Evenly:** Occasionally stir the water to ensure the heat is distributed evenly.
- 6. Children Only Under Supervision:** Children may only use the hot tub under the supervision of an adult.
- 7. Caution with Hot Surfaces:** The metal surfaces of the stove are very hot. Avoid contact and protect children from the risk of burns.
- 8. Empty Ashes Regularly:** Regularly empty the fully cooled ashes from the stove. A designated ash container is provided. The cooled ashes can later be disposed of in the general waste bin.
- 9. Check the Hot Tub After Use:** Allow the wood to burn completely before leaving the hot tub unattended. Please turn off the jets and the lights after using the hot tub.
- 10. Important Note:** Ensure that the hot tub is fully filled with water before heating it. An incompletely filled hot tub can damage the stove and cause a fire hazard.

Contact

+49 (0)9672 81 31 966

info@feriendorf-seeblick.de

www.feriendorf-seeblick.de

Gütenland 28,
92431 Neunburg vorm Wald

We wish you a relaxing time at Eixendorfer See.

Your Feriendorf Seeblick Team